

## Specifications

Material	Silicone + ABS
Size	2.7 * 1.0 * 1.8"
Net Weight	43g
Waterproof	IPX7
Working Frequency	9 frequencies
Working Time	About 60mins
Noise	<50db

**Warning:** Please consult with your physician before using our products. Discontinue use if pain, numbness, swelling, irritation, tingling, loss of feeling or circulation occurs. Never disregard medical advice or delay in seeking treatment. This product is intended to be used by adults for recreational purposes only and is a novelty item.

Find out more online at:  
[WWW.WETFORHER.COM](http://WWW.WETFORHER.COM)

WFH DESIGN USA LLC  
All Right Reserved - order@wetforher.com  
Designed in Miami - Made in China

# WET FOR HER®

# WET FOR HER®

## FlickMe

User manual




@WETFORHER



## Charging instructions

1. Line up device magnets with the charging cable, connecting both. The indicator light will turn on and the button will flash, your device is now charging.
2. Once fully charged, the indicator light will stop flashing.
3. Full charge takes 45 minutes for 60 minutes of continuous playtime.



## Button introduction

1. Press the small button at the tip of the device for 3 sec. to turn on.
2. Gently tap the toy against skin to start vibration.
3. To change between vibration modes, tap the device again. The vibration will cycle between 8 modes each time you tap the device.
4. The device automatically turns off after 5 minutes.

## Care instructions

### Cleaning:

1. Gently clean the device with warm water and soap.
2. Rinse thoroughly with hot water to remove all soap residue.
3. Pat dry with a lint-free or microfiber cloth.

### Storage:

1. Store the device in a clean, dry place away from other materials.
2. Keep out of reach of children.

### Important:

- \* Do not clean the device with alcohol, this can damage the surface and accelerate wear.
- \* The device is waterproof (IPX7). Avoid prolonged exposure to water.