

WET FOR HER®

ThurstHer

User manual



@WETFORHER 

Buttons introduction

Turn on/off

- ⌚ Press the button for 3s to turn the **vibrating** function on or off.
- ⌚ Press the power button repeatedly to cycle through **10 vibration speeds**.


Thrusting function

- ⌚ Press the flash button to turn the **thrusting** function on. Press repeatedly to cycle through **3 thrusting speeds**.
- ⌚ Press the flash button for 3s to turn off the thrusting.

Heating function

- ⌚ While the vibrator is on, quickly press the power button twice for the **heating** function. Red light will flash while heating.
- ⌚ To turn off heating, quickly press the power button twice again.

*Heating function automatically turns off after 5 minutes.




How to charge

1. Charge the device fully before first-time use.
2. Ensure to use the original USB cable (included). Make sure the device is dry and free of moisture or lubricant.
3. Line up device magnet port with the charging cable, connecting both. The power button will flash, signaling the start of charging.
4. Once fully charged, the power button indicator light will stop flashing. Full charge from 0% to 100% takes approximately 120 min.

*Do not use the device while it's charging.

*Do not overcharge the device when it's fully charged.



Magnets for connecting the Charging Cable at the base

Care instructions

Cleaning:

1. This toy is waterproof and easy to clean, please clean it before use. Wash the surface with gentle soap, shower gel or specialized sex toy cleaner, do not boil it.
2. If necessary, use water-based lubricant, do not use oil-based lubricant. The oil-based lubricant may damage the silicone toy.

Storage:

1. Please ensure to turn the device off, store in a clean and dry environment.
2. Please follow charging precautions as mentioned above.

Q&A

Q: What material is this toy made of?

A: The toy is made of high quality liquid silicone material, which is odorless non-toxic, skin-friendly and body-safe.

Q: What if the toy does not work?

A: Check if the battery is fully charged by pressing the power button for 3s. Check if the charging cable is intact. Ensure the power button flashes when charging.

Specifications

Material	Silicone
Size	7.3 * 2.4 * 1.7" (8.5 oz)
Waterproof	IPX6
Working Frequency	10 speeds & 3 thrusting
Working Time	About 60 mins
Noise	< 55 db

Warning: Please consult with your physician before using our products. Discontinue use if pain, numbness, swelling, irritation, tingling loss of feeling or circulatory occurs. Never disregard medical advice or delay in seeking treatment. This product is intended to be used by adults for recreational purposes only and is a novelty item.

Find out more online at:
WWW.WETFORHER.COM

WFH DESIGN USA LLC
All Rights Reserved - order@wetforher.com
Designed in Miami - Made in China



WET FOR HER®